



INSTALLATION INSTRUCTIONS

THE PORTABLE SOLUTION™

PART NUMBER: PS-1324

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM

PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit SOLUTION.

TOOLS REQUIRED: No tools required for this installation.

PARTS INCLUDED: Portable Solution™, belt clip, Nokia® style button, round and oblong buttons, surface preparation cleaning kit and alcohol swab.

INSTRUCTIONS – Please read all instructions thoroughly before installing this product.

IMPORTANT – Do not attempt to apply adhesive to surfaces that have been treated with silicone emulsions (such as Armor All®). **Do not apply adhesive to either surfaces.** To clean the surface selected for mounting the Portable Solution use the provided “Surface Prep” swab following the instructions printed on the pouch; to clean device surfaces use the provided alcohol swab. The working temperature range of the adhesive is -40°F to +200°F, however, do not apply the adhesive when the surface temperatures are lower than +60°F. 3M™ recommends 72-hour curing time for maximum adhesion. The 3M™ adhesive can be removed without damaging the surface. For instructions on removing adhesive, call 1-800-388-0073

Installation Tips for Setting Up Your Phone or Other Hand-Held Device

1. Determine how you will routinely attach the hand-held device to the Portable Solution; the round button works best for devices with a flat back, the oblong button works well with surfaces with a curved back, the button with the metal clip is designed for Nokia 5100 / 6100 series phones or you can most likely use a case with a built-in clip.
2. If using a button with adhesive clean the surface of the device with the alcohol swab (Save the alcohol swab for later use) dry the surface, remove the adhesive backing and then apply the button to the back of the device by applying even pressure to the button for 60 seconds. 3M™ recommends 72-hour curing time for maximum adhesion before use. If using the button with the metal clip designed for Nokia 5100 / 6100 series phones, remove the battery from phone, then slide metal clip into slot on phone and reinstall battery.

Installation Tips for Installing The Portable Solution – PS-1324

1. The Portable Solution is designed to allow many placement options – before installing this product, determine where it will work best for the primary user. Do not apply the Portable Solution where it could block your vision, vehicle airbags or controls such as, but not limited to, gear shifter, climate/radio controls, steering wheel, window/lock controls, vents, etc.
2. Test the installation location before installation because once the Portable Solution is adhered to the surface, **it should not be repositioned or moved.** To perform the test position, put your device in the button slot at the top of the Portable Solution (If using a case with a built-in clip turn the Portable Solution so the button slot is on the bottom. The built-in case clip is inserted into the rectangular slot) and hold to see it meets the requirements noted in the above step.
3. To install the Portable Solution clean the surface with the provided “Surface Prep” swab by following the instructions on the pouch, remove the paper liner from the adhesive, then apply the Portable Solution firmly for 60 seconds to the selected location. 3M™ recommends 72-hour curing time for maximum adhesion before use.



One-Year Limited Warranty

Purchasers of this product have a one-year limited warranty against defects in Material and workmanship. Within the warranty period, any portion of this product that proves to be defective will be repaired or replaced, at our discretion. This warranty does not extend to damage or failure, which results from misuse, neglect, accidents, alterations, abuse, improper installation or maintenance. To exercise this warranty, return the complete product along with the proof of purchase to Pro.Fit International, 1335 Eagandale Court, Eagan, MN 55121

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Express Mount. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation.

Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fax: 651-688-9876

Web Address: www.pro-fit-intl.com